

**Toll-free: 888-609-3779**

Phone: 352-680-3555

Toll-free Fax: 888-242-0652


Fax: 352-680-3559

[www.metalcraftindustries.net](http://www.metalcraftindustries.net)

120 Cypress Road  
Ocala, FL 34472

**Metalcraft  
Industries, Inc.**  
*Significantly Better*

## IN-GROUND BANNER KIT ASSEMBLY INSTRUCTIONS



### PARTS INCLUDED:

- (2) Heavy duty eyelet pole (either 60" or 72")
- (2) Ground stake with plow plate

Tool needed: hammer to drive stake into ground (not included)

1. Attach the eyelet pole to the left and right side of your banner.
2. Once the banner is attached to the poles, lay the banner flat on the ground, stretching it horizontally to full width to get an approximate measurement to mark the ground for the installation of the two ground stakes (one on each side).
3. To begin the installation of the ground stakes, it is suggested to begin one side at a time.  
Hold one ground stake upright with the pole insert facing up and the plow plate pointing downward to the ground.  
NOTE: Be sure the eyelet pole inserts are facing inside with the ground stake shaft pointing outside for best results.
4. Taking your hammer, begin driving the ground stakes into the ground by striking the top of the 1/2" round rod part of the shaft straight down into the ground until the plow plate is firmly below the surface.  
Repeat both steps 3 and 4 for the installation of the second ground stake, but making sure the eyelet pole insert is facing the other ground stake.
5. Once both ground stakes are secure into the ground (bottom of pole pipe should be level with ground), insert each of the banner poles into the stakes.

NOTE: Some adjustment may be necessary to bring the banner taut again, after the banner has rested and/or after significant winds, severe weather or rain.

**WARNING:** BEFORE INSTALLING THE GROUND STAKES, PLEASE INSURE THERE IS NO WIRING, PLUMBING OR ANYTHING THAT COULD BE DAMAGED ON TOP OR UNDER THE GROUND FROM THE INSTALLATION OF THE GROUND STAKES.